



The Quay, Burnham on Crouch, Essex, CM0 8AT, England.

E-mail: Petticrows@petticrows.com

Website: www.petticrows.com

Telephone: +44 1621 782115

Fax: + 44 1621 785389

Tacktack Race Master Compass

How to use the key lock function

To activate the key lock function

<i>ACTION</i>	<i>DISPLAY</i>
Push down arrow until	Line at bottom of display
Hold down spot button	Set up (at top of screen)
Push down arrow	Set up (at top of screen) opt (at bottom of screen)
Push right hand arrow twice	Off key
Push spot button	On key – The key lock function is now on and will activate after 1 minute.
To exit setup – Hold down spot button	Main display
Press left then right buttons	This will deactivate the keylock function for 1 minute.

To turn off key lock function

<i>ACTION</i>	<i>DISPLAY</i>
Push down arrow until	Line at bottom of display
Hold down spot button	Set up (at top of screen)
Push down arrow	Set up (at top of screen) opt (at bottom of screen)
Push right hand arrow twice	On key
Push spot button	Off key – The key lock function is now deactivated
To exit setup – Hold down spot button	Main display